Rate Constant Study of CVBR

In this experiment, a 0.665 L constant volume batch reactor (CVBR) was first filled with

sodium hydroxide solution and heated to reaction temperatures between 21 $^{\circ}$ C and 38.5 $^{\circ}$ C.

The process was operated under isothermal condition and assumed to be well mixed. Ethyl

acetate solution was then injected into the reactor to initiate the reaction. Conductivity of the

solution was measured as a function of time during the experiment under different reaction

temperatures.

The <u>objectives</u> of this experiment were to determine the rate constants using integration and

differential methods and activation energy for the reaction between sodium hydroxide and

ethyl acetate, and to determine the concentration of ethyl acetate at which the reaction starts

to deviate from second order behaviour.

All of the data importing/exporting, cleaning, calculations, statistical analysis and modeling

as well as model evaluations were automated via the creation of the Matlab code. All of the

input data files can be analyzed and the resulting figures (see below) can be generated simply

by running the program.

The following figures are some featured results for demonstration purpose:

1. Integration method modeling

2. Differential method modeling

Raw Data from experiment:

https://docs.google.com/spreadsheets/d/1ZFvqKQYzamdzsqCNKwkONhdC-

TRZnsREnoOWltkoUjE/edit#gid=1645308463

Code (Matlab) for Demo:

https://drive.google.com/file/d/1k8NAUwXnD0cXuHEm6pJ7B1sgXGhUESRq/view?usp=sh

aring

1. Integration method modeling:




Figure 1. $ln((C_{B0}/C_{A0}-x)/(1-x))$ vs. t at 12 different T with predicted regression line after data truncation.

2. Differential method modeling:




Figure 2. dx/dt vs. $C_{A0}*(1-x)*(C_{B0}/C_{A0}-x)$ at 12 different T with predicted regression line after data truncation.